

Product Overview

Valspar Interior / Exterior Contractor Bonding Primer is a high quality latex primer designed for the professional painter. This low odor primer is formulated with unique properties that deliver unparalleled adhesion to the most challenging surfaces such as glossy paint, glass, tile, PVC, weathered aluminum, and masonry. In addition Valspar Bonding Primer is the ultimate stain-blocker and enamel undercoater.

Features/Benefits

- Superior Bonding
 - Eliminates the need for additional surface prep to glossy surfaces
- Interior and exterior application
 - Saves customer money by being able to purchase one primer instead of two
- Stain blocking ability
 - Can be used to seal cigarette smoke, tannin bleed, water damage, grease, mildew stains
 - Fast Drying
- Sandable Primer/Sealer
 - Improves uniformity and depth of sheen when used under glossy topcoats

Where to Use

- Glossy Paint
- Vinyl Siding
- Drywall
- Brick
- Wood
- Plaster
- Galvanized metal and aluminum
- PVC Molding
- Tile
- Glass

Coverage

- Smooth Surfaces 400 sq. ft/gal
- Rough Surfaces 200 sq. ft/gal

Dry Time

- To the touch 30 minutes
- Recoat: 45 minutes

Surface Preparation

General

- All surfaces should be clean and thoroughly dry.
- Remove all surface dirt and chalk with all-purpose cleaner.
- New wood surfaces should have knots and tannin bleed through areas spot primed before priming entire surface.
- Mildew stains should be removed by scrubbing surface with a commercial mildew remover or a solution of 1 part liquid chlorine bleach to 3 parts water.

Concrete, Masonry and Plaster

- Power wash or scrub to remove loose concrete, laitance, efflorescence and dirt.
- New concrete, masonry or plaster should have cured for at least 30 days.

Metal

- This product will seal rust stains on previously painted surfaces and provide an excellent bond for finish coats.
- **It is not, however, formulated to be an anti-rust primer. To fully protect bare iron and steel surfaces from rust, prime with a rust inhibiting oil metal primer.**

Application

- Stir thoroughly before and during use.
- Apply with a premium quality polyester brush, "one coat" roller or airless sprayer.
- Allow to dry at least 45 minutes before applying a latex or oil topcoat.

Additional Items to Complete the Project

- Valspar 2000 paint
- Painter's Tape
- Drop cloth
- Brushes
- Paint tray and liner
- Roller frame
- Roller cover

